





LISTA PARTI DI RICAMBIO - SPARE PARTS LIST

FCE 80 Serie - Series

ITEM N.	DESCRIZIONE	DESCRIPTION	Q.TA' Q.TY	CODICE - CODE							
				FCE 80-125/30	FCE 80-125/40	FCE 80-125/55	FCE 80-160/75	FCE 80-200/110	FCE 80-200/150	FCE 80-200/185	FCE 80-200/220
				102240400 3.0 kW	102240410 4.0 kW	102240420 5.5 kW	102240440 7.5 kW	102240480 11 kW	102240490 15 kW	102240500 18.5 kW	102240510 22 kW
1	Corpo pompa-rasamento-tappi	Pump body-wear ring-plugs	1	151350340				151350360			
* 2	Girante	Impeller	1	150786030	150786100	150786150	150786200	160751480	160751510	160751520	160751530
3	Disco porta tenuta-c/rasamento	Seal housing disc-c/wear ring	1	160150221				150150081			
4	Lanterna	Adaptor	1	161453131	161453141			161452881	161452841		
* 5	Rasamento	Wear ring	1	168601520				168601580			
* 6	Controrasamento	Counterwear ring	1	-				168601270			
* 7	Tenuta meccanica	Mechanical seal	1	002232204				002232801			
* 8	OR	OR	1	002221777				002221788			
9	Motore completo	Complete motor	1	130647063	130647105	130647137	130647143	130647264	130647303	130647313	130647323
	Tipo	Type		LM90B14S2/330	LM112RB14S2/340	LM112B14S2/355	LM112B14S2/375	LM132B14S3/3110	LM160B14S3/3150	LM160B14S3/3185	LM160B14S3/3220
10	Dado fissaggio girante	Impeller locking nut	1	002633002				002633004			
	Rondella	Washer	1	002635072				002635074			
11	Linguetta	Key	1	002650361				002650392			
12	Valvola di sfiato	Air bleed valve	1	159300050							
13	Anello distanziale	Spacer ring	1	-							

* Parti di ricambio consigliate - Recommended spare parts